



Proxy- and SSL/TLS-Connection Settings



Windows start menu
Link for calling the
application settings

Proxy- and SSL/TLS-Connection Settings



IBus settings

Communication Cache Licence Look & Feel

Default: R [Test connection ...]

Set connection manually: SSL/TLS ENX JNDI

Certificate files for SSL/TLS

Keystore: C:\Users\...\infobus\SSL\...ks.p12

Truststore: C:\Users\...\infobus\SSL\client.ts

Network proxy

No proxy

Address: 192.168.xxx.xxx : 8080

Use system proxy settings Use authentication

Manual proxy configuration

User: username Password:

Save Close

KUKA Exchange Portal Settings

Proxy Address

IP or DNS of the proxy server, usually similar to the browser settings.

Proxy Port

Proxy server port, complies to the browser settings.

Proxy Authentication

Optional user and password for authentication at the proxy server.